
Camshaft position sensor (CMPS)
B/Y
Br
G/W
G/Bl
Crankshaft position sensor (CKPS)
P/B
R
Throttle position sensor (TPS)
Y/W
Secondary throttle position sensor (STPS)
G/B
Intake air pressure sensor (IAPS)
G/Y
Atomospheric pressure sensor (APS)
B/Bl
Engine coolant temperature sensor (ECTS)
G/B
Intake air temperature sensor (IATS)
B
B/Br
Tip-over sensor (TOS)
O/W
W
W/G
HO2 sensor
Speedometer
ECM
G/R
R/Bl
Gr/W
Gr/B
Gr/Y
Gr/R
Y/R
Y/B
O/G
W/Bl
B
Y
G
W/G
P
Y/G
B/Y
B/W
P/W
B/Lg
W/B
G
1
2
3
4
Fuel injector (FI)
Fuel pump
Fuel pump relay
Ignition coil (IG COIL)
PAIR solenoid
Gear position switch
N
1
2
3
4
5
6
Secondary throttle valve actuator (STVA)
Cooling fan motor
Fan relay
15 A
10 A
15 A
10 A
30 A
Engine stop switch
To immobilizer
Ignition switch
Side-stand relay
Neutral indicator light
Side-stand switch
Starter switch
Starter relay
Clutch lever position switch
Starter motor